


COMMANDER 160
Wall/Pipe-mounted
Universal Process Indicator

User Guide



Use of Instructions



Warning.

An instruction that draws attention to the risk of injury or death.



Note.

Clarification of an instruction or additional information.



Caution.

An instruction that draws attention to the risk of damage to the product, process or surroundings.



Information.

Further reference for more detailed information or technical details.

Although **Warning** hazards are related to personal injury, and **Caution** hazards are associated with equipment or property damage, it must be understood that operation of damaged equipment could, under certain operational conditions, result in degraded process system performance leading to personal injury or death. Therefore, comply fully with all **Warning** and **Caution** notices.

Information in this manual is intended only to assist our customers in the efficient operation of our equipment. Use of this manual for any other purpose is specifically prohibited and its contents are not to be reproduced in full or part without prior approval of Technical Communications Department, ABB Instrumentation.

Health and Safety

To ensure that our products are safe and without risk to health, the following points must be noted:

1. The relevant sections of these instructions must be read carefully before proceeding.
2. Warning labels on containers and packages must be observed.
3. Installation, operation, maintenance and servicing must only be carried out by suitably trained personnel and in accordance with the information given.
4. Normal safety precautions must be taken to avoid the possibility of an accident occurring when operating in conditions of high pressure and/or temperature.
5. Chemicals must be stored away from heat, protected from temperature extremes and powders kept dry. Normal safe handling procedures must be used.
6. When disposing of chemicals ensure that no two chemicals are mixed.

Safety advice concerning the use of the equipment described in this manual or any relevant hazard data sheets (where applicable) may be obtained from the Company address on the back cover, together with servicing and spares information.

GETTING STARTED

The COMMANDER 160 is a development of the COMMANDER 150 1/8 DIN indicator and uses the same programming procedures. It also compliments the COMMANDER 310 universal controller giving an IP66 indicator in the same case, providing a retransmission output and three alarm relays, with the option to add MODBUS™ RS485 communications.

This manual is divided into 5 sections which contain all the information needed to install, configure, commission and operate the COMMANDER 160. Each section is identified clearly by a symbol as shown below.



Displays and Controls

- Displays and function keys
- LED Indication
- Error Messages



Operator Mode (Level 1)

- Operator menus for:
 - *Standard Indicator*
 - *Totalizer/Batch Controller*
 - *Maximum/Minimum/Average Indicator*



Set Up Mode (Level 2)

- Alarm trip points
- Totalizer functions



Configuration Mode (Levels 3 and 4)

- Accessing the configuration levels
- Level 3
 - Hardware assignment and input type
 - Alarm types and hysteresis
 - Operator functions and totalizer setup
 - Digital input and serial communications
- Level 4
 - Ranges and passwords



Installation

- Siting
- Mounting
- Electrical connections

Symbol Identification and Section Contents

CONTENTS


Section	Page
GETTING STARTED	1
1 DISPLAYS AND FUNCTION KEYS	3
1.1 Introduction	3
1.2 Use of Function Keys	4
1.3 LED Alarms and Indicators	5
1.4 Error Messages	6
2 OPERATOR MODE	7
2.1 Introduction	7
2.2 Operating Page – Standard	8
2.3 Operating Page – Totalizer	9
2.4 Operating Page – Math Functions	11
3 SET UP MODE	13
3.1 Introduction	13
3.2 Set Up Level (Level 2)	14
4 CONFIGURATION MODE	18
4.1 Introduction	18
4.2 Accessing the Configuration Mode	18
4.3 Basic Configuration	20
4.3.1 Hardware Assignment and Input Type	20
4.3.2 Alarms	22
4.3.3 Operator Functions and Totalizer Set Up	26
4.3.4 Digital Input and Serial Communications	28
4.4 Ranges and Passwords	30
5 INSTALLATION	33
5.1 Siting	33
5.2 Mounting	35
5.3 Cable Glands and Conduit Fixings	37
5.3.1 Cable Glands (IEC – 20mm)	37
5.3.2 Conduit Adapters (N. American – 0.5 in.)	37
5.3.3 Cable Glands (N. American – 0.5 in.)	38
5.4 Electrical Connections	39
5.4.1 Relay Contact Ratings	39
5.4.2 Arc Suppression	39
5.4.3 Logic Output	39
5.4.4 Retransmission Analog Output	39
5.4.5 Digital Input	39

1 DISPLAYS AND FUNCTION KEYS



Information.

The fold-out page inside on the back cover of this manual shows all the frames in the programming levels. Space is provided on the page for writing the programmed setting or selection for each frame.



1.1 Introduction – Fig. 1.1

The COMMANDER 160 front panel display, function keys and LED indicators are shown in Fig. 1.1.




Fig. 1.1 Front Panel Display, Function Keys and Indicators

1.2 Use of Function Keys – Fig. 1.2












Fig. 1.2 Use of Function Keys

1.3 LED Alarms and Indicators



1.4 Error Messages

Display	Error/Action	To Clear Display
	Calibration error Turn mains power off and on again (if the error persists contact the Service Organization).	Press the  key
	Configuration error The configuration and/or setup data for the instrument is corrupted. Turn mains power off and on again (if error persists, check configuration/setup settings).	Press the  key
	A to D Converter fault The analog to digital converter is not communicating correctly.	Turn mains power off and on again. If the error persists, contact the Service Organization
	Process variable over/under range	Restore valid input
	Option board error Communications to the option board have failed.	Contact the Service Organization



2 OPERATOR MODE

2.1 Introduction

Operator Mode (Level 1) is the normal day-to-day mode of the COMMANDER 160.

Frames displayed in level 1 are determined by the indicator functions which are selected during configuration of the instrument – see Section 4.




Note. Only the operating frames relevant to the configured functions are displayed in Operator Mode.

The three indicator functions are:

- **Standard Indicator** – page 8
- **Indicator with Totalization** – page 9
- **Indicator with Max./Min./Average** – page 11



2.2 Operating Page – Standard (Level 1)




*1 Displayed only if there is an active latch alarm.



2.3 Operating Page – Totalizer (Level 1)

These frames are displayed only if the totalizer function is enabled in the configuration level – see Section 4.3.3




- 1 Totalizer stop/go and reset from these frames can be disabled – see Section 4.3.3.

A digital input can also be used to start/stop or reset the totalizer – see Section 4.3.4



...2.3 Operating Page – Totalizer (Level 1)




- 1 The predetermined value should be greater than the preset value when the totalizer is counting up and lower than the preset value when the totalizer is counting down.

- 2 Displayed only if enabled in the configuration level – see Section 4.3.3.



2.4 Operating Page – Math Functions (Level 1)

* **Note.** It is possible to display totalizer and math functions together.



- 1 This frame can be disabled – see Section 4.3.3.

The reset function in this frame can be disabled – see Section 4.3.3.

The average value is reset automatically on power-up and can also be reset from a digital input – see Section 4.3.4.




...2.4 Operating Page – Math Functions (Level 1)



Maximum Value

This is the maximum value of the process variable since the maximum was reset.




- rSt-y – reset
- rSt-n – do not reset

To reset the maximum value, select rSt-y then press the key.




Minimum Value

This is the minimum value of the process variable since the minimum was reset.




- rSt-y – reset
- rSt-n – do not reset

To reset the minimum value, select rSt-y then press the key.




Security Code

Enter the correct code to access the setup level or the configuration level.



- [0 to 9999]
-



Level 1

Note. To select this frame from anywhere in this page, press and hold the key.


•1 This frame can be disabled – see Section 4.3.3.

The reset function in this frame can be disabled – see Section 4.3.3.

The average value is reset automatically on power-up and can also be reset from a digital input – see Section 4.3.4.

3.1 Introduction

To access the Set Up Level (Level 2) the correct set up or configuration level password must be entered in the security password frame (*Code*) in Level 1 – see Sections 2.2 to 2.4.



3.2 Set Up Level (Level 2)

Level 2

 **Note.** To select this frame from anywhere in this level, press and hold the  key.

Alarm 1 Trip Point

Alarm type: *R l h P* = High process

R l L P = Low process

R l H L = Latched high process

R l L L = Latched low process

R l F r = Fast Rate

R l S r = Slow Rate



Process and Latched Alarms in Eng. units.

Rate Alarms ± 0.5 to 500% of Eng. Span/hr.

Alarm 1 Hysteresis Value



[In engineering units]

Alarm 2 Trip Point

Alarm type



[In engineering units]

Alarm 2 Hysteresis Value



[In engineering units]

Continued on next page.

- 1 Not displayed if the alarm is disabled ('None' selected) – see Section 4.3.2.
- 2 Displayed only if custom alarm hysteresis is selected – see Section 4.3.2
Not displayed if 'Rate' Alarm type is selected.



...3.2 Setup Level (Level 2)

	A3hP	<p>Alarm 3 Trip Point Alarm type</p> <p>[In engineering units]</p>
	*	
	3003	<p>▲</p> <p>▼</p>
	A3 HYS	<p>Alarm 3 Hysteresis Value</p> <p>[In engineering units]</p>
	*	
	34.6	<p>▲</p> <p>▼</p>
	123456	<p>Totalizer Value</p> <p>rst-y – reset rst-n – do not reset</p> <p>To reset the maximum value, select <i>rst-y</i> then press the [*] key.</p>
	*	
	rst-n	<p>▲</p> <p>▼</p>
	t-GO	<p>Totalizer Stop/Go</p> <p>t-GO – start totalizer t-STOP – stop totalizer</p> <p>Setting to <i>t-GO</i> starts the totalizer counting towards the predetermined value. Setting to <i>t-STOP</i> holds the totalizer at its present value.</p>
	▲	
	t-STOP	<p>▼</p>
	SECT01	<p>Continued on next page</p>

- 1 Not displayed if the alarm is disabled ('NONE' selected) – see Section 4.3.2
- 2 Displayed only if custom alarm hysteresis is selected – see Section 4.3.2
Not displayed if 'Rate' Alarm type is selected.
- 3 Displayed only if enabled in the Configuration Level – see Section 4.3.3
- 4 A digital input can also be used to reset the batch total.

...3.2 Set Up Level (Level 2)

SECT00^{*1}

Secure Total
The secure total is independent of the batch total value. When 999999 or 000000 is reached, the total is reset and then continues counting.

Total
456789

Reset

r5t-y – reset totalizer
r5t-n – do not reset totalizer

To reset, select r5t-y then press the [*] key.

PrESEt^{*2}

Preset Batch Total
This is the value the batch total is set to when it is reset.
[000000 to 999999]

PrEdEt^{*2}

Predetermined Batch Total
When this value is reached the batch total either resets (with wrap on) or stops (wrap off) – see Section 4.3.3.
[000000 to 999999]

R 140.5

Continued on next page.

- *1 Displayed only if enabled in the Configuration Level – see Section 4.3.3.
- *2 The preset value must be lower than the predetermined value when counting up, and greater than the predetermined value when counting down.



...3.2 Set Up Level (Level 2)

Average Value
 This is the mean average value of the process variable input since the average was reset.

^{*1}

$rSt - y$ – reset
 $rSt - n$ – do not reset

To reset, select $rSt - y$ then press the key.

Maximum Value
 This is the maximum value of the process variable since the maximum was reset.

^{*2}

$rSt - y$ – reset
 $rSt - n$ – do not reset

To reset, select $rSt - y$ then press the key.

Minimum Value
 This is the minimum value of the process variable since the minimum was reset.

^{*2}

$rSt - y$ – reset
 $rSt - n$ – do not reset

To reset, select $rSt - y$ then press the key.

Offset Adjustment
 An offset can be applied to the process variable input to enable spot calibration or the removal of system errors.

$\pm 10\%$ of engineering range]

- 1 The average value is reset automatically on power-up and can also be reset from a digital input – see Section 4.3.4.
- 2 The maximum and minimum values are reset automatically on power-up and can also be reset from a digital input – see Section 4.3.4.



4 CONFIGURATION MODE

4.1 Introduction

The Configuration Mode comprises two levels (3 and 4) as shown in Fig. 4.2.

Configuration level 3 is divided into four frames. For most simple applications it is only necessary to set up the parameters in the first frame.



Note.

When in the configuration level:

- All the l.e.d. indicators flash.
- All relays and logic outputs are turned off.
- The analog output reverts to 0% (4mA) output level.

4.2 Accessing the Configuration Mode – Fig. 4.1

The Configuration Mode is accessed by entering the correct password in level 1 (see Sections 2.2 to 2.4). The configuration password is set up in level 4.




Fig. 4.1 Accessing the Configuration Level (Levels 3 and 4)




Fig. 4.2 Configuration Levels



4.3 Basic Configuration (Level 3) – Fig. 4.3

4.3.1 Hardware Assignment and Input Type

LEVEL 3



A 1P.C0



B 1P.C0



C 1P.C0



d 1P.C0

E 1203

Level 3

Note. To select this frame from anywhere in this level, press and hold the key for a few seconds.

'R b C d' Settings

The first character (R, b, C or d) identifies the parameter to be changed. The current setting is indicated by a flashing letter. Parameter options are shown in Fig. 4.3.

- R = Hardware configuration
- b = Input type and range
- C = Temperature units
- d = No. of decimal points

Note. For custom settings contact the local distributor.

Continued on page 22.



Information.

Count High Calculation

Convert flow rate into units/sec = $\frac{\text{actual engineering flow rate}}{\text{flow range time units (in seconds)}}$

Count High = $\frac{\text{units/sec}}{\text{counter factor}}$ resultant must be >0.001 and <99.999pps.

Counter factor is the engineering value of the least significant digit shown on the totalizer display – see Section 4.3.3.

Totalizer Count Pulse

The totalizer count pulse is on for a preset time of 250ms and off for a minimum of 250ms.


R 1P.C0 A – Hardware Configuration

Supply Hz		Relay 1 Source	Relay 2 Source	Relay 3* Source	Logic O/P Source	Analog O/P Source
50	60					
1	R	Alarm 1	Alarm 2	Alarm 3	TCP**	PV
2	b	Alarm 1	Alarm 2	Alarm 3	TWP**	PV
3	c	TCP**	Alarm 1	Alarm 2	TWP**	PV
4	d	TWP**	Alarm 1	Alarm 2	TCP**	PV
5	E	Alarm 1	Alarm 2	Alarm 3	TCP**	PV Average
U		Custom	Custom	Custom	Custom	Custom

TCP = Totalizer Count Pulse TWP = Totalizer Wrap Pulse PV = Process Variable

* Not available if MODBUS™ option fitted.

** Pulse energizes assigned relay

b 1P.C0 B – Input Type and Range Configuration

Display		Display	
b	THC Type B	1	0 to 20 mA
E	THC Type E	2	4 to 20 mA
J	THC Type J	3	0 to 5 V
K	THC Type K	4	1 to 5 V
N	THC Type N	6	0 to 50 mV
R	THC Type R	7	4 to 20 mA (square root linearizer)
S	THC Type S	U	Custom Configuration
T	THC Type T		
P	PT100 RTD		

C 1P.C0 C – Temperature Units

Display	Temperature Units
C	Degrees C*
F	Degrees F*
0	No temperature units

* Temperature inputs only

d 1P.C0 D – Process Variable Display Decimal Places


Display	
0	xxxx
1	xxx . x
2	xx . xx
3	x . xxx
4	x . xxxx

Fig. 4.3 Hardware Configuration and Input/Output Ranges



4.3.2 Alarms – Figs. 4.4, 4.5 and 4.6

***** **Note.** All relays are de-energized in the alarm state.



'EFGH' Settings

The first character (*E*, *F*, *G* or *H*) identifies the parameter to be changed. The current setting is indicated by a flashing letter. Parameter options are shown in Fig. 4.4.

- E* = Alarm 1 type
- F* = Alarm 2 type
- G* = Alarm 3 type
- H* = Alarm hysteresis

***** **Note.** For custom settings contact the local distributor.

Continued on page 26.



E 0000 E – Alarm 1 Type

Display	
0	None
1	High Process
2	Low Process
3	High Latch
4	Low Latch
5	Fast Rate
6	Slow Rate

F 0000 F – Alarm 2 Type

Display	
0	None
1	High Process
2	Low Process
3	High Latch
4	Low Latch
5	Fast Rate
6	Slow Rate

G 0000 G – Alarm 3 Type

Display	
0	None
1	High Process
2	Low Process
3	High Latch
4	Low Latch
5	Fast Rate
6	Slow Rate

h 0000 H – Alarm Hysteresis

Display	
0	None
1	0.1%
2	0.2%
3	0.5%
4	1.0%
5	2.0%
6	5.0%
U	Custom

} Value in % of engineering range


} Value in engineering units *


* **Note.** When custom alarm hysteresis is selected, the alarm hysteresis values are set individually in the **Set Up Level** – see Section 3.2.

Fig. 4.4 Alarm Setup



...4.3.2 Alarms – Figs. 4.4, 4.5 and 4.6





Information. The example above shows a fast rate alarm with a trip value of 10% of the Engineering Span per hour on an engineering range of 0.0 to 100.0. The time taken to detect whether an alarm condition is present or has cleared is calculated as follows:


$$t = 10.81 + \frac{1800}{\text{trip value}(10\% \text{ eng span per hour})}$$

$$t = 191 \text{ seconds}$$

Fig. 4.6 Rate Alarm Action




4.3.3 Operator Functions and Totalizer Set Up – Fig. 4.7



'JPLn' Settings

The first character (*J*, *P*, *L* or *n*) identifies the parameter to be changed. The current setting is indicated by a flashing letter. Parameter options are shown in Fig. 4.7.

- J* = Totalizer set-up
- P* = No. of decimal places for totalizer
- L* = Operator level frame enable
- n* = Operator level functions enable/disable

 **Note.** For custom settings contact the local distributor.

Continued on page 28.


J 0000 J – Totalizer Setup

Display	
0	Off
1	Count Up, Wrap Off
2	Count Up, Wrap On
3	Count Down, Wrap Off
4	Count Down, Wrap On

P. 0000 K – Totalizer Display
Decimal Places

Display	
0	xxxxxx
1	xxxxx.x
2	xxxx.xx
3	xxx.xxx
4	xx.xxxx
5	x.xxxxx

L 0000 L – Operator Level Frame Enable

Display	Max/Min Values Displayed	Average Value Displayed	Preset/Predetermined Values Displayed
0	No	No	No
1	Yes	No	No
2	Yes	Yes	No
3	No	Yes	Yes
4	No	No	Yes
5	Yes	No	Yes
6	Yes	Yes	Yes

This frame determines which frames appear in the operating page (level 1)

n 0000 N – Operator Level Math Function & Totalizer Control Enable


Display	Totalizer Stop/Go	Totalizer Reset	Max./Min./Average
0	No	No	No
1	Yes	No	No
2	No	Yes	No
3	Yes	No	Yes
4	No	Yes	Yes
5	Yes	Yes	Yes

This frame determines which functions the operator can control

Fig. 4.7 Totalizer Setup and Operator Functions




4.3.4 Digital Input and Serial Communications – Figs. 4.8 and 4.9




'PrSt' Settings

The first character (*P*, *r*, *S* or *t*) identifies the parameter to be changed and the current setting is indicated by a flashing letter. Parameter options are shown in Fig. 4.9.

- P* = Digital input function
- r* = Analog input filter
- S* = Serial communications configuration
- t* = Serial communications parity

 **Note.** For custom settings contact the local distributor.

Continued on page 30.



Information.

Digital input options 1, 2, 3 and 5 are edge-triggered to enable the front panel keys to change the function when the digital input is operational.

Fig. 4.8 Digital Function Configuration



P 0000 P – Digital Input Function

Display	
0	None
1	Totalizer Reset
2	Totalizer Stop/Go
3	Average, Max/Min Reset
4	Front Panel Lockout
5	Alarm Acknowledge

r 0000 R – Analog Input Filter

Display	
0	0 seconds
1	1 second
2	2 seconds
5	5 seconds
R	10 seconds
b	20 seconds
ƒ	40 seconds
D	60 seconds

S 0000 S – Serial Communication Configuration

Display	Baud Rate, 2/4 Wire
0	Off
1	2400, 2-Wire
2	2400, 4-Wire
3	9600, 2-Wire
4	9600, 4-Wire

t 0000 T – Serial Communication Parity

Display	
0	None
1	Odd
2	Even




Note. Settings for options P, S and T are only available if the appropriate option board is fitted.

Fig. 4.9 Digital Function and Serial Communications Configuration




4.4 Ranges and Passwords (Level 4)



- 1 The engineering range high and low values are automatically set to the maximum allowed value when thermocouple or RTD is selected in the Configuration Level – see Section 4.3.1. This value can be modified if required.



...4.4 Ranges and Passwords (Level 4)



- 1 The retransmission range high and low values are automatically set to the maximum allowed value when thermocouple or RTD is selected in the configuration level – see Section 4.3.1. This value can be modified if required.



...4.4 Ranges and Passwords (Level 4)

		Totalizer Count High This frame determines the count corresponding to the full-scale input.
		[0.000 and 99.999 pulses/second]
		Cut-off This frame sets the lowest flow value at which the totalizer is to stop counting.
		[In engineering units]
		Setup Password This password enables access to the set-up level (Level 2).
		[0 to 9999]
		Configuration Password This password enables access to the configuration levels. (Levels 3 and 4).
		[0 to 9999]
		MODBUS™ Address This frame sets the MODBUS™ address.
		[1 to 99]

•1 Displayed only if enabled in the configuration level – see Section 4.3.3.

•2 Available only if the appropriate option board is fitted.




5 INSTALLATION

EC Directive 89/336/EEC


In order to meet the requirements of the EC Directive 89/336/EEC for EMC regulations, this product must not be used in a non-industrial environment.

5.1 Siting – Figs 5.1 and 5.2






...5.1 Siting – Figs 5.1 and 5.2






5.2 Mounting – Figs. 5.3 and 5.4

The instrument is designed for wall-mounting or pipe-mounting (see Fig. 5.4). The pipe-mounting kit (part no. 4600/0138) is suitable for both vertical and horizontal pipes. Overall dimensions are shown in Fig. 5.3.






...5.2 Mounting – Figs. 5.3 and 5.4





5.3 Cable Glands and Conduit Fixings

5.3.1 Cable Glands (IEC – 20mm) – Fig. 5.5



**Fig. 5.5 Cable Gland
(Supplied as Standard)**

5.3.2 Conduit Adapters (N. American – 0.5 in.) – Fig. 5.6



Warning.

- Rigid conduit must NOT be fitted to the Indicator.
- Indicator adapters must incorporate a face seal.
- Torque settings for the hubs and outer nuts on the specified adapters is 20ft.lbs minimum, 25ft.lbs. maximum.

...5.3.2 Conduit Adapters (N. American – 0.5 in.) – Fig. 5.6



Information.

- Suitable adapters for indicator (mandatory for FM installations):
 APPLETON
 ST-50 PLUS STG-50 or
 STB-50 PLUS STG-50.
 Reusable ONLY with
 replacement ferrule STF-50.
 O.Z. GEDNEY
 4Q-50, 4Q50T or 4Q-50TG.




Fig. 5.6 Conduit Adapters



5.3.3 Cable Glands (N. American – 0.5 in.) – Fig. 5.7



Warning.

- Indicator glands must be fitted with a face seal.
- Torque settings (hubs only) – 20ft. lbs minimum, 25ft. lbs. maximum.
- Outer nuts – hand tight plus a half turn only.



Information.

- Suitable Cable Glands: (mandatory for FM installations):
O.Z. GEDNEY SR-50-375 or SR-504
APPLETON CG 3150 or CG-3150S (and STG-50 sealing ring).
THOMAS & BETTS 2521.
- When fitting cable glands to the Indicator, start with an outer gland and also temporarily fit a gland at the opposite end, to aid location of the transmitter gland plate. Fit and tighten glands consecutively from initial gland.




Fig. 5.7 Cable Glands



5.4 Electrical Connections – Fig. 5.8



Warning. Before making any connections, ensure that the instrument power supply, any powered control circuits and high common mode voltages are switched off.



Note. The analog output and the logic output share a common positive and can be used at the same time.

5.4.1 Relay Contact Ratings

Relay contacts are rated at:

115/230V a.c. at 5A (non-inductive)

250V d.c. 25W max.

5.4.2 Arc Suppression

Arc suppression components are fitted to relays 2 and 3 only. If relay 1 is required to switch inductive loads, the arc suppression components supplied must be fitted.

5.4.3 Logic Output

18V d.c. at 20mA

Min. load 900 Ω

Isolation 500V from input (not isolated from retransmission output)

5.4.4 Retransmission Analog Output

Max. load 15V (750 Ω at 20mA)

Isolation 500V from input (not isolated from logic output)



Note. Problems may be encountered if the retransmission analog output is connected to devices with a very fast sampling rate. A 100 μ F 63V electrolytic capacitor can be fitted across terminals 8 (+ve) and 20 (-ve).



5.4.5 Digital Input

Type: Volt-free

Minimum pulse: 250 ms



...5 INSTALLATION



* Fit 100Ω resistor supplied

** Fit arc suppression components


Fig. 5.8 Electrical Connections



CUSTOMER CONFIGURATION LOG



LEVEL 3



LEVEL 4

ENG HI

R 1XCO

ENG LO

A _ B _ C _ D _

rEt HI

E 0000

rEt LO

E _ F _ G _ H _

CnE HI

J 0000

CUTOFF

J _ K _ L _ N _

S-PASS

P 0000

C-PASS

P _ R _ S _ T _

Addr.

CUSTOMER SETUP LOG



LEVEL 1

Code

LEVEL 2

R 1xx

R 2xx

R 3xx

xxxxxx

t-GO

SEctot

PrESEt

PrEdEt

R xxxx

H xxxx

L xxxx

ORdJ

Instrument Serial Number: _____

Product Code: C 1 6 0 / _ _ _ _ / _ _ _ _

Customer Support

ABB Instrumentation provides a comprehensive after sales service via a Worldwide Service Organization. Contact one of the following offices for details on your nearest Service and Repair Centre.

United Kingdom

ABB Instrumentation Limited

Tel: +44 (0)1480 475321

Fax: +44 (0)1480 470787

United States of America

ABB Automation Inc.

Instrumentation Division

Tel: +1 215-674-6000

Fax: +1 215-674-7183

Italy

ABB Kent-Taylor SpA

Tel: +39 (0) 344 58111

Fax: +39 (0) 344 58278

Client Warranty

Prior to installation, the equipment referred to in this manual must be stored in a clean, dry environment, in accordance with the Company's published specification. Periodic checks must be made on the equipment's condition.

In the event of a failure under warranty, the following documentation must be provided as substantiation:

1. A listing evidencing process operation and alarm logs at time of failure.
2. Copies of operating and maintenance records relating to the alleged faulty unit.



The Company's policy is one of continuous product improvement and the right is reserved to modify the information contained herein without notice.

© ABB 2000

Printed in UK (8.00)

ABB Instrumentation Ltd

St. Neots
Cams.
England, PE19 3EU
Tel: +44 (0) 1480 475321
Fax: +44 (0) 1480 217948

**ABB Automation Inc.
Instrumentation Division**

125 E. County Line Road
Warminster, PA 18974 USA
Tel: +1 215-674-6000
Fax: +1 215-674-7183

ABB Kent-Taylor SpA

22016 Lenno
Como
Italy
Tel: +39 (0) 344 58111
Fax: +39 (0) 344 58278